

MAINTENANCE MANAGEMENT SYSTEM

MMS™ Air-Identify™

Mobile control device



Equiplite MMS™ Air-Identify™



When opening the box you will notice that the Air-Identify is in a case.:

1. Micro / standard USB cabel
2. (((RFID))) USB Reader.

You get an email with the following:

- Username
- Password

Please change your password after the first login



ACTIVATED YOUR ACCOUNT TO MMS-SCANNER

The login screen for the Equiplite Maintenance Management System. It features the Equiplite logo and the text "Please Sign In". There are two input fields: "Username" and "Password". Below the fields is a green "Log In" button.

Wifi Connected

1. Go to:
<http://service.equiplite.eu/ frontend/login/login.php>
2. Fill in your username and password you received by email.
3. Click on Log In

The "Scan Tag" screen in the Equiplite Maintenance Management System. It shows a search bar for "Scan Tag" with a question mark icon. Below the search bar is a "Tag" input field. There are "Read Tag" and "Reset" buttons. Below the input fields is a "Products" section with a grid icon and a "Sold Products" section.

You will see this screen with the following information:

- Scan Tag form
- Your personal products

The "Scan Tag" screen in the Equiplite Maintenance Management System, showing the "Tag" input field selected with a blue border. The rest of the screen is the same as the previous screenshot.

Before you scan your product you have to click on the empty tag field.

This field is selected whenever it has a blue line around it.

Now you can scan your product.

SCAN PRODUCT

To get the information of the product do the following:

1. Remove the Velcro®
2. Place the scanning side of the scanner above the wifi symbol.
2. Hold the MMS-Scanner till the information is shown on your screen. If the product is not recognised, try again!



Equiplite®
Maintenance Management System

CORE Block | 26-100-10 CB
Position: Not assigned MWL: 11.000 kg

Product Information

Project:		Service:	
Project:	Real Show Model	Purchase date:	Not set
Supplier:	No Supplier	Final service date:	Not set

Comments

Add comment

The MMS-Scanner shows the Position

Equiplite®
Maintenance Management System

CORE Block | 26-100-10 CB
Position: Not assigned MWL: 11.000 kg

Product Information

Project:		Service:	
Project:	Real Show Model	Purchase date:	Not set
Supplier:	No Supplier	Final service date:	Not set

Comments

Add comment

The MMS-Scanner shows the Service date

Equiplite®
Maintenance Management System

CORE Block | 26-100-10 CB
Position: Not assigned MWL: 11.000 kg

Product Information

Project:		Service:	
Project:	Real Show Model	Purchase date:	Not set
Supplier:	No Supplier	Final service date:	Not set

Comments

Add comment

The MMS-Scanner shows the MWL