



Sneek, The Netherlands

## Equiplite® EQ 3D | LOOP™ 360° Installation and data sheet.

Dear Customer,

Thank you for purchasing this Equiplite® product.

### General

Equiplite® products employ a proprietary SK loop to take the majority of the load in 3D | Loop™ 360°

**Equiplite® 3D | LOOP™ 360° Splice Technology** works at a lower percentage of ultimate tensile strength (UTS), reducing EQ Loop™ stress and fatigue.

### Important installation Note ( Riggers )

Before the **first sail trial** it's very important to pre-tension | line out the Equiplite 3D | Loop™ 360°, between both ends, to 50% of the MWL of the EQ 3D Loop™ 360°

- Equiplite® equipment is warranted for 12 months from the date of sale to be free of defective material and workmanship and must be used in accordance with specifications and accepted good practice.
- Loops should be connected to a mating part that is rounded and free from sharp edges or burrs.
- Connectors should be free to align themselves with the load. 3D Loop™ 360 when used should not be constrained so that the load is not in line, or damage of the side plates may occur.
- By final installation make sure to stitch the Velcro on to each other.**

Fittings will last indefinitely if the above is followed.

### Maintenance

- Recoat black UV coating periodically to prevent UV damage for long life.
- After sailing in salt water, cleaning loops with fresh water will avoid extra wear.
- Loops should be replaced if excessive wear occurs and mating parts should be checked.
- Equiplite provides world-wide service for your Equiplite products.

[service@equiplite.com](mailto:service@equiplite.com)

We hope that this data sheet will help you with the easy installation and maintenance of our products.

Best Regards,  
Equiplite®